



• Rev. 01

Last version of this manual

IP2437EN • 2024/12/04

Ditec



Technical manual

Ditec ION4B - ION6B

Sliding gates

(translation of the original instructions)

GENERAL SAFETY PRECAUTIONS FOR THE USER



WARNING! Important safety instructions • Please follow these instructions carefully •

Failure to observe the information given in this manual may lead to severe personal injury or damage to the equipment • Keep these instructions for future reference.



WARNING! Disconnect power supply before any cleaning or maintenance operation • This

manual and those for any accessories can be downloaded from www.ditecautomations.com

This installation manual is intended for qualified personnel only • Installation, electrical connections and adjustments must be performed by qualified personnel, in accordance with Good Working Methods and in compliance with the current regulations • Read the instructions carefully before installing the product. Wrong installation could be dangerous • Before installing the product, make



sure it is in perfect condition • The packaging materials (plastic, polystyrene, etc.) should

not be discarded in the environment or left within reach of children, as they are a potential source of danger • Do not install the product in explosive areas and atmospheres: the presence of inflammable gas or fumes represents a serious safety hazard • Make sure that the temperature

range indicated in the technical specifications is compatible with the installation site • Before installing the motorization device, make sure that the existing structure, as well as all the support and guide elements, are up to standards in terms of strength and stability. Verify the stability and

smooth mobility of the guided part, and make sure that no risks of fall or derailment subsist. Make all the necessary structural modifications to create safety clearance and to guard or isolate all the crushing, shearing, trapping and general hazardous areas • The motorization device manufacturer

is not responsible for failure to observe Good Working Methods when building the frames to be motorized, or for any deformation during use • The safety devices (photocells, safety edges, emergency stops, etc.) must be installed taking into account the applicable laws and directives, Good Working

Methods, installation premises, system operating logic and the forces developed by the motorized door or gate • The safety devices must protect against crushing, cutting, trapping and general danger areas of the motorized door or gate. Display the signs required by law to identify hazardous



areas • Each installation must bear a visible indication of the data identifying the motorized

door or gate • Before connecting the power supply, make sure the plate data correspond to those of the mains power supply. An omnipolar disconnection switch with a contact opening distance of at least 3 mm must be fitted on the mains supply. Check that there is an adequate residual

current circuit breaker and a suitable overcurrent cutout upstream of the electrical installation in accordance with Good Working Methods and with the laws in force • When requested, connect the motorized door or gate to an effective earthing system that complies with the current safety

standards • Before commissioning the installation to the end user, make sure that the automation is adequately adjusted in order to satisfy all the functional and safety requirements, and that all the command, safety, and manual release devices operate correctly • During maintenance and repair

operations, cut off the power supply before opening the cover to access the electrical parts • The



protection cover of the operator must be removed by qualified personnel only • The electronic

parts must be handled using earthed antistatic conductive arms. The manufacturer of the motorization declines all responsibility if component parts not compatible with safe and correct operation are fitted • Only use original spare parts for repairing or replacing products • The installer must supply all information concerning the automatic, manual and emergency operation of

the motorized door or gate, and must provide the user with the operation and safety instructions.

Declaration of incorporation of partly completed machinery

(Directive 2006/42/EC, Annex II-B)

We,
ASSA ABLOY Entrance Systems AB
Lodjursgatan 10
SE-261 44 Landskrona
Sweden,

Declare, under our sole responsibility, that the type of equipment with the name:

Ditec ION4B-6B automation for swing gates

Complies with the following directives and their amendments:

2006/42/EC Machinery Directive (MD), regarding the following essential health and safety requirements:

1.1.2, 1.1.3, 1.2.1, 1.2.2, 1.2.3, 1.2.4.2, 1.2.6, 1.3.9, 1.4.3, 1.7.2, 1.7.3, 1.7.4, 1.7.4.1, 1.7.4.2.

2014/30/EU Electromagnetic Compatibility Directive (EMCD)

2014/53/EU Radio Equipment Directive (RED)

2011/65/EU Restriction of Hazardous Substances (RoHS 2)

2015/863/EU Restriction of Hazardous Substances (RoHS Amendment 2)

Harmonised European standards which have been applied:

EN IEC 55014-2:2021

BS EN IEC 55014-2:202

EN IEC 61000-6-1:2019

BS EN IEC 61000-6-1:2019

EN IEC 61000-6-3:2021

BS EN IEC 61000-6-3:2021

ETSI EN 301 489-1 V2.2.3

ETSI EN 301 489-3 V2.3.2

ETSI EN 301 489-17 V3.2.4

ETSI EN 300 220-1 V3.1.1

ETSI EN 300 220-2 V3.2.1

ETSI EN 300 328 V2.2.2

EN IEC 62311:2020

Other standards or technical specifications which have been applied:

EN 60335-1:2012 + AC:2014 + A11:2014 + A13:2017 + A1:2019 + A2:2019 + A14:2019 + A15:2021

BS EN 60335-1:2012 + A15:2021

EN 60335-2-103:2015

BS EN 60335-2-103:2015

EN IEC 62368-1:2020 + A11:2020 + AC:2020

IEC 62368-1:2018 + COR1:2020

The manufacturing process guarantees that the equipment complies with the technical documentation.

Do not put equipment into service until the installed finished Automatic Entrance System has been declared compliant with Directive 2006/42/EC on Machinery.

Responsible for the technical documentation:

Matteo Fino
Ditec S.p.A.
Largo U. Boccioni, 1
21040 Origgio (VA)
Italy

Signed on behalf of ASSA ABLOY Entrance Systems AB by:

Place

Date

Signature

Position

Origgio

2024/12/04

Matteo Fino

CEO Ditec



© ASSA ABLOY, All rights reserved

UK Declaration of Conformity

We:

ASSA ABLOY Entrance Systems AB
Lodjursgatan 10
SE-261 44 Landskrona
Sweden

Declare under our sole responsibility that the types of equipment with names:

Ditec ION4B-6B automation for swing gates

Complies with the following directives and their amendments:

- Supply of Machinery (Safety) Regulations 2016
- Electromagnetic Compatibility Regulations 2016
- Radio Equipment Regulations 2017
- The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012 (RoHS)

Harmonized European standards that have been applied:

EN IEC 55014-2:2021	BS EN IEC 55014-2:202
EN IEC 61000-6-1:2019	BS EN IEC 61000-6-1:2019
EN IEC 61000-6-3:2021	BS EN IEC 61000-6-3:2021
ETSI EN 301 489-1 V2.2.3	ETSI EN 301 489-3 V2.3.2
ETSI EN 301 489-17 V3.2.4	ETSI EN 300 220-1 V3.1.1
ETSI EN 300 220-2 V3.2.1	ETSI EN 300 328 V2.2.2
EN IEC 62311:2020	

Other standards or technical specifications that have been applied:

EN 60335-1:2012 + AC:2014 + A11:2014 + A13:2017 + A1:2019 + A2:2019 + A14:2019 + A15:2021	
BS EN 60335-1:2012 + A15:2021	EN 60335-2-103:2015
BS EN 60335-2-103:2015	EN IEC 62368-1:2020 + A11:2020 + AC:2020
IEC 62368-1:2018 + COR1:2020	

The manufacturing process ensures the compliance of the equipment with the technical file.

Responsible for technical file:

Matteo Fino
Ditec S.p.A.
Largo U. Boccioni, 1
21040 Origgio (VA)
Italy

Signed for and on behalf of ASSA ABLOY Entrance Systems AB by:

Place	Date	Signature	Position
Origgio	2024/12/04	Matteo Fino	CEO Ditec



INDEX

General safety precautions	3
Declaration of incorporation of partly completed machinery	4
UK Declaration of Conformity	5
1. Technical data	6
2. Applications of use	7
3. Operating instructions	8
4. Machinery Directive	8
5. Dimensions	8
6. Standard installation.....	9
7. Main components	10
7.1 Manual release label.....	10
8. Installation	11
8.1 Preliminary checks.....	11
8.2 Base plate position	12
8.3 Gearmotor installation	13
8.4 Rack installation	14
8.5 Operation with virtual encoder.....	14
8.6 Installation of optional accessories	15
8.6.1 Magnetic limit switches (ref. NES100FCM)	15
8.6.2 Battery kit (ref. BBK750X2)	16
8.6.3 Remote release handle (ref. IONSBM-ASR2)	17
8.6.4 Chain kit (ref. IONC)	18
9. Electrical connections.....	19
10. LCU50DC card	20
10.1 ION4B-6B parallel installation layout	21
11. Commands and safety device.....	22
11.1 Commands inputs	22
11.2 Safety inputs	23
12. Outputs and accessories	24
13. Jumper setting.....	25
14. Segnalazioni LED	25
15. Using of the menus	26
15.1 Switching the display ON and OFF.....	26
15.2 Navigation keys.....	26
16. Parameters LCU50DC	27
16.1 Main level menu.....	27
16.2 Frequent use menu map	27
16.3 Complete menu map.....	28
16.4 "Frequent use" menu - parameters description.....	30
16.5 Complete menu - parameters description.....	33
17. Signals visualised on the display	48
17.1 Display of automation status.....	48
17.2 Display of safety devices and commands	50
17.3 Visualisation of alarms and faults	51
18. Troubleshooting	54

Key



This symbol indicates instructions or notes regarding safety, to which special attention must be paid.











This symbol indicates useful information for the correct functioning of the product.



Default values

1. Technical data


	Ditec ION4B	Ditec ION6B
Maximum stroke	20 m	
Maximum gate weight	400 kg	600 kg
Gate speed	0,1 ÷ 0,3 m/s	
Thrust	200 N nominali 600 N Spunto	300 N nominali 800 N Spunto
Power supply	100 - 240 V~, 50-60 Hz	100-120 V~ / 200-240 V~ (selectable by switch), 50-60 Hz
Fuse	 In case of 120 V power supply, switch the selector of the power supply unit	
Power	T3.15A	T5A
Standby	100 W	150 W
Service class	< 0,6 W (unplugged accessories)	
Intermittence	INTENSIVE (tested up to 150.000 cycles)	
Cycles / hour *	S2= 60 min (T= 25°C) S3= 70% (T= 25°C)	
Continuous cycles *	40 (T= 25°C)	
Lifespan	56 (T= 25°C)	
Usage temperature (T)	50,000 to 150,000 cycles depending on the conditions indicated in the table (see product durability charts)	
Degree of protection	<div>  -20°C  +55°C <div>  -35°C  +55°C with active NIO </div> </div>	
Motor output	IP44	
Power supply to accessories	24V  10A max	
Control panel	24V  0,3A max	
Radio frequency	LCU50DC	
Storable radio codes	433.92 MHz (RD → FD → 43) - default 868.35 MHz (RD → FD → 86)	
Noise level LpA	 RCB100E receiver module included	
Codici radio memorizzabili	cod. BIXMR2 100= (RD → MU → MU / 10) 200= (RD → MU → MU / 20)	
Livello di rumore LpA	≤70 dB (A)	

* Indicative cycles considering a 6 m wing and factory settings (default speed of 20 cm/s). ION4B / ION6B allows a maximum speed of 30 cm/s (configurable). A cycle is considered an opening followed by a closing.


Index of conditioning factors			
		ION4B	ION6B
Gate wing weight	>150Kg	10	-
	>200Kg	20	10
	>300Kg	30	20
	>400Kg	-	30
Gate wing width	>4m	20	10
	>8m	-	20
Wheel diameter <100mm		10	
Saline environment		10	
Safety edge installed		10	
R1/R2 > default		10	
VA/VC > default		10	
OC/CB < default		10	

Example of lifespan calculation for ION4B

Gate wing weight>250Kg	20
Saline environment	10
Safety edges installed	10
VA/VC > default	10
Total stress index	50
Estimated lifespan - 80,000 cycles	
Estimated daily cycles 22 (for 10 years)	



2. Applications of use



3. Operating instructions

Use: For single-family/multi-family or commercial entrances with heavy driveway or pedestrian use.


- The class of service, usage times and number of consecutive cycles are suggestions. They are statistically measured under average usage conditions and cannot be certain for every single case.
- For each automatic entrance, there are variables such as friction, balancing and environmental conditions that can substantially change the operating life and quality of the automatic entrance or some of its components (including the automated mechanisms). It is up to the installer to implement safety factors appropriate for each particular installation.

4. Machinery Directive


According to the Machinery Directive (2006/42/EC), the installer who motorises a door or gate has the same obligations as the manufacturer of a machine, and as such must:

- prepare the technical documentation, which must contain the documents indicated in Annex V of the Machinery Directive (the technical documentation must be kept and made available to the competent national authority for at least ten years, starting from the date of construction of the motorised door);
- draw up the EC statement of conformity according to Annex II-A of the Machinery Directive and hand it over to the customer;
- affix the CE marking to the motorised door in accordance with point 1.7.3 of Annex I of the Machinery Directive.

5. Dimensions




6. Standard installation



Ref.	Code	Description	Cable
1	Ditec ION4B - ION6B	Actuator ION with LCU50DC control panel	3G x 1.5 mm ²
A		Connect the power supply to a type-approved omnipolar switch, with a contact opening distance of at least 3mm (not supplied). See chapter 6. The connection to the mains must follow an independent path, separate from the connections to the control and safety devices.	
2	ZEN	Transmitter	/
	FLM	Flashing light	2 x 1 mm ²
3	FL24	Antenna (integrated in the flashing light)	RG-58 coax cable (50 Ω)
	AXK4	Digital combination wireless keypad	/
	AXK5M	Wall-mounted key-operated selector switch with European cylinder	4 x 0.5 mm ²
	AXK5N	Semi-recessed key-operated selector switch with European cylinder	
	AXK5NM	Wall-mounted key-operated selector switch without cylinder	
	AXK5NI	Semi-recessed key-operated selector switch without cylinder	
	AXR7	RFID reader unit	5 x 0.5 mm ²
5	LIN2 - LIN2B AXP2 - LAB4	Photocells	4 x 0.5 mm ²
6	SOFAP20 - SOF2M20 SOF3M20 - SOFA15 SOFA20-SOFA25	Safety edge	2 x 0,5 mm ² min
7	GOPAV	Radio system for sensitive edges	/
8	LAB9	Magnetic loop	2 x 1,5 mm ²

7. Main components




Ref.	Descripción
1	Motor
2	Control panel
3	Key release
4	Pinion
5	Cable inlet
6	Power supply terminal and fuse
7	Power supply
8	Anchorage base

7.1 Manual release label

In case of failure or power failure, insert and turn the key clockwise, open the door fully. Manually open the gate.

To re-lock the gate, close the door, turn the key counterclockwise and remove the key.



8. Installation

The given operating and performance features can only be guaranteed with the use of DITEC accessories and safety devices.

Unless otherwise specified, all measurements are expressed in mm.

8.1 Preliminary checks

Check the stability of the wing (derailing and lateral falls) and the sliding wheels and that the upper guides do not cause any friction.

The sliding guide must be securely fixed to the ground for the full length within doorway and must have no irregularities that could hinder the movement of the wing.

The opening and closing stops must be fitted.

If the gate has slits, make sure they are covered to prevent shearing points or install active safety edges on the columns.




WARNING: Make sure that the gate can not exit the sliding guides and fall. Make sure that the protection system and any manual release function correctly.

8.2 Base plate position


Make a concrete base with the anchor ties and base plate embedded, which must be level and clean and of the size indicated in the figure.

i **NOTE:** if the concrete base has already been made, base plate can be fixed using M8 plugs (not supplied).





8.3 Gearmotor installation

- Release the gearmotor [1] (see OPERATING INSTRUCTIONS).
- Loosen the front screw [2] and remove the casing by pressing on its sides [3-4].



NOTE: during the vertical adjustment, keep the gearmotor slightly raised from the base plate so that the rack can be fixed and subsequent adjustments are possible.




- Place the gearmotor on the base plate.
- Adjust the gearmotor horizontally by sliding it along the slots of the gearmotor base and vertically with four levelling screws [A].
- After adjusting, fix the gearmotor using screws [B].



WARNING: the gearmotor must be suitably raised from the ground to avoid flooding. Tighten the [B] screws using a tightening torque of 20-25 Nm.

8.4 Rack installation



- Release the gearmotor (see OPERATING INSTRUCTIONS) and open the gate.
- Place the rack against the pinion and sliding the gate manually fix it along its whole length.



NOTE: To make it easier to align the rods correctly, use a scrap piece of rack and rest it underneath the junction point, as shown in the figure detail.

- Once fixed, vertically adjust the gearmotor to give a play of about 2 to 3 mm between the pinion and the rack.
- Secure the gearmotor with the [B] screws using a tightening torque of 20-25 Nm.
- Slightly lubricate the rack and pinion after assembly.
Manually check that the gate slides evenly and without friction.

8.5 Operation with virtual encoder

ION4B-ION6B gearmotors do not require limit switches because they have a virtual encoder. Mechanical opening and closing end stops must be installed. The gate automatically slows when approaching the end stops.



WARNING: when the gate reaches the opening or closing limit stop, it reverses briefly (parameters `RR` \rightarrow `DD`; `RR` \rightarrow `DE`) to facilitate manual release of the gearmotor.

8.6 Installation of optional accessories

8.6.1 Magnetic limit switches (ref. NES100FCM)



NOTE: The limit switch kit is used to stop the gate before it reaches the opening and closing mechanical stops. With a limit switch installed, slowdown is carried out at regulated power to overcome possible friction.


To position the limit switches, you can use the menu **3F** → **1F**.

The display shows the status of the limit switches:

- **FR**: opening limit switch configured and activated;
- **FC**: closing limit switch configured and activated;
- **NO**: (both parts of display active): opening limit switch not configured and activated;
- **NO**: (no part of display active): closing limit switch not configured and activated;
- **NO**: (central part of display active): no limit switch activated.

With the limit switches configured as STOP (**FR**= **5#**; **FC**= **5#**) the anti-violation function is activated. When the automation stopped open or closed, if the gate backs off releasing the limit switch, it is brought back into position avoiding openings from external forces [energy saving must be disabled **ES**= **0F**].

NES100FCM



For complete instructions see manual:





NES100FCM

8.6.2 Battery kit (ref. BBK750X2)



NOTE: The battery kit guarantees operation if there is a power cut.
For advanced control of battery-powered operation, refer to the **ID** → **BT** menu.




For complete instructions
see manual:




BBK750X2

8.6.3 Remote release handle (ref. IONSBM-ASR2)

IONSBM



ASR2




For complete instructions see manual:




IONSBM-ASR2

8.6.4 Chain kit (ref. IONC)



i NOT INCLUDED - 1pcs, roller chain DIN8187 ISO/R 606 ISO standard 081
- 2pcs, spring link clip ISO standard 081




For complete instructions
see manual:



IONC

9. Electrical connections




! Before connecting the power supply, make sure that the data on the plate correspond to the electricity distribution network data. Provide an omnipolar switch/disconnector on the power network with a contact opening distance of 3 mm or more. Check that there is a suitable residual-current device and surge protector upstream of the electrical system. Use an H05RN-F 3G1.5 electrical cable and connect it to terminals L (brown) and N (blue) inside the automation system. Connect the earth cable \oplus (yellow/green) to the earth terminal. Secure the cable by means of the cable clamp (A) and only unsheathe it at the terminal.

! **ATTENTION:** always observe L-N polarity when connecting to the mains and close all unused clamps.


Secure the cable by means of the cable clamp (A) and only unsheathe it at the terminal. Connections to the electrical distribution network and any other low-voltage conductors (120 V AC - 230 V AC), in the section outside the automation system, must be made with corrugated pipes that are independent and separate from the path of connections to the control and safety devices (SELV= Safety Extra Low Voltage). Make sure there are no sharp edges that could damage the power cord.

! **ATTENTION :** Ensure that the mains connection cables, any other low-voltage cables (120 V AC - 230 V AC), and safety extra-low voltage safety accessory connection cables in the portion located inside the product are kept well separated from the gear motor body (B).


10. LCU50DC card



In case of using the standard antenna, the following measures are recommended:



10.1 ION4B-6B parallel installation layout



WARNING: In case of parallel installation, Bluetooth and WiFi cannot be used.

11. Commands and safety device



NOTA: You are advised to read paragraph 13 for all the details about the possible adjustments.



Warning: terminal 30 (common positive for commands) has the same functions as terminal 1, so the commands visualised on the display are indicated with **F5**, **F3**, **F4**, etc. It is different from terminal 1, however, because of the maximum current that can be dispensed and it is also active when the control panel is in standby **E5** → **OM**.




Warning: make a jumper for all NC contacts if not used, or deactivate them via the relative menu. Terminals with the same number are equal.








11.1 Commands inputs

Function	Command	Description
NO	STEP-BY-STEP	When selecting IO → FS → F5 , the closure of the contact NO activates a sequential opening or closing operation: opening-stop-closing-opening. WARNING: if automatic closure is enabled, the stop mode is selected by OM → SS .
	OPENING	The "opening-stop-closing-opening" sequence can be changed to "opening-stop-closing-stop-opening" by selecting OM → PP . When selecting IO → FS → F3 , the closure of the contact activates an opening operation
NC	STOP	The opening of the safety contact causes the current operation to stop. If IO → PP → SP , automatic closure is disabled when contact 30-9 recloses. If IO → PP → ST , automatic closure is enabled when contact 30-9 recloses. NOTE: the flashing light flashes.
NO	PARTIAL OPENING	The closure of the contact activates a partial opening operation. Once the automation stops, the partial opening control performs the opposite operation to the one performed before the stop.
NC	AUTOMATIC CLOSURE	Selecting IO → 20 → F2 , the permanent closure of the contact enables automatic closure if OM → RC → F2 .





11.2 Safety inputs

Function		Command	Description
	SAFETY TEST		Insert the GOPAVRS device in the slot for plug-in boards AUX. To activate the safety test, appropriately configure the parameters IO → 36 e IO → 38 . If the test fails, an alarm message appears on the display.
NO	CLOSURE	1 ——— 6	When selecting IO → 64 → 14 , closing the contact activates a closing operation.
NC	SAFETY STOP	1 ——— 6	When selecting IO → 64 → 16 , opening of the safety contact stops and prevents any movement. NOTE: to set different safety contact functions, see the IO → 5H parameter settings.
NC	CLOSING SAFETY DEVICE	1 ——— 8	The opening of the NC contact triggers a reversal of the movement (reopening) during the closing operation: When selecting IO → 50 → 0H , with the automation idle (gate closed or partially open) all operations are prevented. When selecting IO → 50 → 0F , with the automation idle (gate closed or partially open) opening operations are permitted.
NC	CLOSING/ OPENING SAFETY DEVICE	1 ——— 6 └─ 8	The opening of the safety contact stops and prevents any movement. NOTE: During the closing operation, the opening of the safety contact stops and reverses the movement. During the opening operation, the opening of the safety contact stops the movement


12. Outputs and accessories


Function	Output	Value of accessories	Description
Power supply to accessories		24 V _{DC} / 0.3 A	Output for power supply to external accessories. NOTE: the maximum absorption of 0.3 A corresponds to the sum of all terminals 1.
Configurable output		24 V _{DC} 25 W (1 A)	Factory configured output LP as ON-OFF flashing light LP → 03 . The pre-flashing settings can be selected from the menu 0M → W0 and/or 0M → W0 . To modify the operating mode of the LP output, refer to the selection 10 → LP .
Configurable output		24 V _{DC} 2 W (0.1 A)	Output 30-13 factory configured as proportional gate open indicator light. 13 → 05 . To change the operation mode of output 13 refer to the selection 10 → 13 .
WARNING: When connecting higher loads, it is recommended to use an interface relay with external power supply (e.g., electric lock)			
Radio antenna			When using the standard antenna, the following measurements are recommended: 433 MHz (175 mm) - 868 MHz (90 mm). Use a RG-58 type coaxial cable (50 Ω) to connect an external antenna (ref. GOL148REA).
Plug-in accessory seat	AUX	BIXR2 BIXPR2 BIXLR42 LAB9 LAN7S GOPAVRS	The control panel has a slot for plug-in command and safety cards. The action of the control card can be defined by selecting 10 → RM . When using slot-in radio boards, remove the RX module. The display will show RV .
Radio receiver module			Radio receiver module RCB100E (as standard) configurable from control panel: - 433.92 MHz (RO → FO → 43) - default - 868.35 MHz (RO → FO → 86) Modulo ricevitore radio RCB50E compatibile (opzionale)
Modulo memoria radiocomandi	COM 	BIXMR2	This allows the functioning configurations to be saved using the function 0F → 5V . The saved configurations can be recalled using the function 0F → RC . The storage module allows the remote controls to be stored. If the control panel is replaced, the storage module being used can be inserted in the new control panel.
WARNING: the storage module must be inserted and removed with the power supply disconnected, and paying attention to the positioning direction.			
DC power supply			Power supply: 36 V DC In battery operation mode, when the power supply is off: 24 V DC. The batteries are kept charged when the power supply is on. If the power supply is off, the panel is powered by the batteries until the power is re-establish or until the battery voltage drops below the safety threshold. The control panel turns off in the last case. NOTE: the operating temperature of the rechargeable batteries is from +0°C to +40°C. To check the voltage level of the batteries refer to the menu 0F → BL .


13. Jumper setting


Jumper	Description	OFF 	ON 
JR1	Display mode selection.	Display mode. Only the values and parameters present can be displayed.	Maintenance mode. Only the values and parameters present can be displayed and modified. Activated maintenance mode is indicated by the permanent switching on of the right-hand point on the display.
JR2	Selection of power supply - auxiliary board.	<div>130</div> AUX1 powered from 0-1. (default). With ES → ON it turns off during power saving mode	<div>130</div> AUX1 powered from 0-30. Always supplied.



14. Segnalazioni LED



J2
SCI




J26


JR1




 LED



Red LED 	Green LED 	Description
off	off	Board off or not working.
1 Flashe every second	off	LCU board on and functioning. RCB (radio/BLE/WiFi) board absent or not working.
off	1 Blink every second	LCU board on and functioning. RCB50E (radio) board present and functioning
off	2 Flashes every second	LCU board on and functioning. RCB100E (radio/BLE) board present and functioning
off	3 Flashes every second	LCU board on and functioning. RCB200E (WiFi) board on SCI present and functioning
off	4 Flashes every second	LCU board on and functioning. RCB50E (radio) + RCB200E (WiFi) board present and functioning.
off	5 Flashes every second	LCU board on and functioning. RCB100E board (radio/BLE) + RCB200E (WiFi) present and functioning

15. Using of the menus






NOTE: pressure on the keys may be quick (less than 2 s) or prolonged (longer than 2 s). Unless specified otherwise, quick pressure is intended. To confirm the setting of a parameter, prolonged pressing or double prolonged pressing is necessary.

15.1 Switching the display ON and OFF

The procedure to switch ON the display is as follows:


MAIN LEVEL





- Display visualizes by default the left dot ;
- Press the  key;
- The display functioning check starts;
- The main level menu is displayed.

The procedure to switch OFF the display is as follows:


MAIN LEVEL







 The display switches off (and it returns to visualize left dot ) automatically after 60 seconds of inactivity.

15.2 Navigation keys




MAIN LEVEL PARAMETER LEVEL VALUE



MAIN LEVEL







- Press  or  to scroll through the menus.
- Press  to go in **PARAMETER LEVEL**.
- Press  to exit from a sub-menu.

PARAMETER LEVEL




















- Press  or  to scroll through the parameters inside the specific sub-menu.
- To set a parameter, select the desired **VALUE** and press  for 2 seconds or by prolonged double confirmation to save.

16. Parameters LCU50DC

16.1 Main level menu

Display		Description
Complete menu		Frequent use The menu allows to manage the most commonly used parameters to customize the functionalities of the automation
		Operation Mode The menu allows to manage all the parameters used for operation modes of the automation (type of automation installed, predefined settings, automatic closure, etc.)
		Run Adjustment The menu allows to adjust all the run parameters (opening/closure speed, slowdown positions, obstacle thrust sensibility etc.)
		Input/Output Configuration The menu allows to configure the inputs/outputs functionalities of the automation (selection of devices connected to the terminals, photocells, flashing light/electro-lock setting, etc.)
		Radio Operations and Connectivity The menu is used to manage all parameters for the radio/wireless functions of the control panel
		Diagnostic Functions The menu allows to manage all other parameters used for additional services (diagnostic counters, FW updating, energy saving, etc.)

16.2 Frequent use menu map

MAIN LEVEL	
	FU - Frequent Use
PARAMETER LEVEL	
	AS - Selection of the automation
	DM - Open direction
	EP - Setting encrypted messages of remote control transmission (AES 128bit and PROTECTED mode)
	SR - Remote control storage
	RM - Operation mode of the radio receiver
	T5 - Terminal 5 operation mode
	AC - Automatic closure enabling
	TC - Setting of automatic closing time [s]
	RP - Adjustment of partial opening measurement [%]
	TP - Setting of automatic closing time after partial opening [s]
	R1 - Adjustment of thrust on obstacles and motor current during opening
	R2 - Adjustment of thrust on obstacles and motor current during closure
	VA - Opening speed [cm/s]
	VC - Closing speed [cm/s]
	R9 - Configuration of input 30-9
	D6 - Selection of device connected to terminals 1-6 an with safety test
	D8 - Selection of device connected to terminals 1-8 and with safety test
	S0 - Terminal 1-8 operation mode with automation stopped

16.3 Complete menu map

MAIN LEVEL	
OM	OM - Operation Mode
PARAMETER LEVEL	
AS	AS - Selection of the automation
DM	DM - Open direction
AC	AC - Automatic closure enabling
TC	TC - Setting of automatic closing time [s]
RP	RP - Adjustment of partial opening measurement [%]
TP	TP - Setting of automatic closing time after partial opening [s]
PP	PP - Setting of step-by-step sequence
S9	S9 - STOP mode in the step-by-step sequence from command 1-5.
SS	SS - Duration of STOP in step-by-step sequence from command 1-5
TS	TS - Setting of renewal of automatic closing time after PH safety device release [%]
WO	WO - Setting of pre-flashing time on opening [s]
WC	WC - Setting of pre-flashing time on closing [s]
NI	NI - Activation of anti-freeze system NIO
TN	TN - NIO intervention temperature and automatic ramps
HS	HS - Automatic ramp adjustment
TH	TH - High temperature protection enable
VL	VL - Vacation lock/unlock
DS	DS - Display mode
PS	PS - Predefined setting
RA	RA - Run Adjustment
PARAMETER LEVEL	
VA	VA - Opening speed [cm/s]
VC	VC - Closing speed [cm/s]
R1	R1 - Adjustment of thrust on obstacles and motor current during opening
R2	R2 - Adjustment of thrust on obstacles and motor current during closure
OB	OB - Adjustment of deceleration distance during opening [cm]
CB	CB - Adjustment of deceleration distance during closing [cm]

PO	PO - Adjustment of approach speed during opening
PC	PC - Adjustment of approach speed during closing [cm/s]
OO	OO - Obstacle detection limit during opening
OC	OC - Obstacle detection limit during closure
VR	VR - Learning speed setting
VM	VM - Initial movement speed
TA	TA - Adjustment of acceleration time on opening
TQ	TQ - Adjustment of acceleration time on closure
TD	TD - Deceleration time adjustment during opening
TU	TU - Deceleration time adjustment during closure
DO	DO - Duration of disengagement on stop during opening
DC	DC - Setting of disengagement on stop during closure [mm]
DE	DE - Setting of disengagement after edge intervention [cm]
ST	ST - Start-up time adjustment
DT	DT - Obstacle recognition time adjustment
MP	MP - Start-up at maximum power
OT	OT - Selection of type of obstacle
IO	IO - Input/Output Configuration
PARAMETER LEVEL	
FA	FA - Selection of opening limit switch mode
FC	FC - Selection of closing limit switch mode
R9	R9 - Configuration of input 30-9
T5	T5 - Terminal 5 operation mode
64	64 - Functioning of safety stop/closing command
AM	AM - Operation of AUX plug-in control board
20	20 - Partial opening command of terminal 30-20
PT	PT - Fixed partial opening
D6	D6 - Selection of device connected to terminals 1-6
SM	SM - Selection of operating mode for device connected to terminals 1-6
D8	D8 - Selection of device connected to terminals 1-8

50	SO - Terminal 1-8 operation mode when open
68	68 - Selection of the device simultaneously connected to terminals 1-6 and 1-8
LP	LP - Function of output +LP-
13	13 - Function of output 13
LU	LU - Setting the courtesy light switch-on extra time [s]
LG	LG - Switch-on time for independently commanded courtesy light
LR	LR - Electric lock release time
PV	PV - Power supply via solar panels (future use)
ES	ES - Energy-saving
LB	LB - Signal for batteries almost flat
LL	LL - Voltage threshold for indicating when the batteries are almost flat
BO	BO - Battery mode

RD RD - Radio Operations and Connectivity

PARAMETER LEVEL	
EP	EP - Setting encrypted messages
SR	SR - Remote control storage
RM	RM - Radio receiver operation
TX	TX - Visualization of counter showing remote controls stored
MU	MU - Setting of the maximum number of remote controls that can be stored in the memory
ER	ER - Deletion of a single remote control
EA	EA - Total memory deletion
C1C2C3C4	C1, C2, C3, C4 - Selection of CH1, CH2, CH3, CH4 function of stored remote control
RE	RE - Setting of memory opening via remote control
MS	MS - Compatibility setting with older generation GOL4 remote controls
RK	RK - Menu navigation via remote control keypad
FQ	FQ - Radio frequency selection
BT	BT - Bluetooth® mode
WF	WF - Setting of WiFi functionality

WR	WR - Request to restart the connected WiFi device (in particular Apple HomeKit)
MA	MA - Mobile App access management

DF DF - Diagnostic Functions

PARAMETER LEVEL	
SP	SP - Password setting
IP	IP - Password insertion
CU	CU - Visualization of the firmware version on the control panel
UP	UP - Firmware update
AL	AL - Alarm counter
AH	AH - Alarm log
AR	AR - Alarm reset
CV	CV - Display of total operations counter
CP	CP - Display of partial operations counter
ZP	ZP - Reset of partial operations counter
CA	CA - Setting the maintenance alarm (factory setting - alarm deactivated: 0.0 00. 00)
OA	OA - Selecting maintenance alarm display mode
CH	CH - Display of power supply hour counter
BH	BH - Visualization of counter for power supply hours via battery
SV	SV - Saving user configuration on control panel storage module
RC	RC - Configuration loading
RL	RL - Loading of last configuration set
EU	EU - Erasing of user configurations and last configuration set in the storage module
IM	IM - Motor current visualization
TB	TB - Visualization of the internal temperature of the automation
TT	TT - Visualisation of maximum and minimum temperatures recorded
TF	TF - Limit switch test. Visualises FR / FC (N.O. / NO if they are not configured)
BL	BL - Visualization of Battery voltage level
EL	EL - Efficiency level of the automation
RD	RD - Resetting of factory settings

Il menu permette di gestire i parametri più utilizzati per personalizzare le funzionalità dell'automazione.

NOTE: the card performs a restart after a new value is selection.



WARNING: in case of replacement card, the display flashes **H0** alarm. No operation is allowed. The **R5** parameter must be first configured. This operation must be performed by qualified personnel.



- RT - Right
- LF - Left




EP - Setting encrypted messages of remote control transmission (AES 128bit mode and protected mode)



If the possibility to receive coded messages is enabled, the control panel will be compatible with remote controls of the "ENCRYPTED" or Protected type.

- **ON** - Enabled
- **OF** - Disabled


SR - Memorizzazione di un radiocomando



By pressing (ESC) starts flashing and it is possible to associate the desired buttons.

After **OK** is displayed, **(5P)** flashes again on the display and it is possible to associate the next button. To exit, press  or  for 2 seconds and move on to the next item.



NOTE: if the display shows  flashing, the remote control may already be stored.



RM - Radio receiver operation

RR - Radio Receiver operation
This is the function associated to radio command when only one channel is stored (independently which one is)

- 1-5 - Step-by-step
- 1-3 - Opening




T5 - Terminal 5 operation mode
































This parameter is associated to the functionality of the terminal 30-5

- 1-5 - Step-by-step
- 1-3 - Opening

AC - Automatic closure enabling

- **OF** - Disabled
- **ON** - Enabled
- **1-2** - Dependent on input at terminal 20 (parameter **20** must set to **12**)



		<p>TC - Setting of automatic closing time [s] It is set with different intervals of sensitivity:</p> <ul style="list-style-type: none"> • from 0" to 59" with intervals of 1 second • from 1'0 to 1'5 with intervals of 10 seconds <p>For each interval, the display visualizes:</p> <ul style="list-style-type: none"> - 10 → 1 minute and 10 seconds - ... - 15 → 1 minute and 50 seconds • from 2' to 4' with intervals of 1 minute 	 
		<p>RP - Adjustment of partial opening measurement [%] This parameter adjusts the percentage of partial opening in relation to the total opening of the automation.</p> <ul style="list-style-type: none"> • from 10 to 99 % with intervals of 1 % 	
		<p>TP - Setting of automatic closing time after partial opening [s] It is set with different intervals of sensitivity.</p> <ul style="list-style-type: none"> • from 0" to 59" with intervals of 1 second • from 1'0 to 1'5 with intervals of 10 seconds <p>For each interval, the display visualizes:</p> <ul style="list-style-type: none"> - 10 → 1 minute and 10 seconds - ... - 15 → 1 minute and 50 seconds • from 2' to 4' with intervals of 1 minute 	 
		<p>R1 - Adjustment of thrust on obstacles and motor current during opening [%] The control panel is provided with a safety device which, in the case of an obstacle:</p> <ul style="list-style-type: none"> - the movement is stopped, if outside the obstacle detection limit space, performs a disengagement operation. <p>NOTE: the obstacle detection limit space when opening is defined by the type of limit switch installed, in the absence of a limit switch it is determined by the selection RR → 00.</p> <ul style="list-style-type: none"> • 00 – Minimum thrust (minimum current delta for obstacle detection) • 99 – Maximum thrust (maximum current delta for obstacle detection) <p>The threshold is calculated dynamically as a delta on the motor current measured during the opening stroke.</p>	
		<p>R2 - Adjustment of thrust on obstacles and motor current during closing [%] The control panel is provided with a safety device which, in the case of an obstacle:</p> <ul style="list-style-type: none"> - closing, outside of the detection limit space, the system invert the movement; - closing, in the detection limit space, the system stoped the movement. <p>NOTE: the obstacle detection limit space when closing is defined by the type of limit switch installed, in the absence of a limit switch it is determined by the selection RR → 00.</p> <ul style="list-style-type: none"> • 00 – Minimum thrust (minimum current delta for obstacle detection) • 99 – Maximum thrust (maximum current delta for obstacle detection) <p>The threshold is calculated dynamically as a delta on the motor current measured during the closing stroke.</p>	
		<p>VA - Opening speed [cm/s]</p> <ul style="list-style-type: none"> • from 10 to 30 cm/s with intervals of 1 cm/s 	

		VC - Closing speed [cm/s] • from 10 to 30 cm/s with intervals of 1 cm/s	 10 ...  30  20
		R9 - Terminal 9 operation mode • NO - Disabled • 9P - Open state of the input triggers a permanent stop (default) • 9T - Open state of the input triggers a temporary stop. Once contact closes, an automatic closure time is activated (if enabled) • HR - With the input open, the automation operates in "operator present" mode	 NO  9P  9T  HR
		D6 - Selection of device connected to terminals 1-6 • NO - None • PH - Photocells • P41 - Photocells with safety test • SE - Safety edge (if contact 1-6 opens, there is a disengagement of 10 cm after the stop) • S41 - Safety edge with safety test (if contact 1-6 opens, after the stop there is a disengagement of a duration depending on the selection  → )	 NO  PH  P41  SE  S41
		D8 - Selection of device connected to terminals 1-8 • NO - None • PH - Photocells • P41 - Photocells with safety test • SE - Safety edge (if contact 1-8 opens, there is a disengagement of 10 cm after the stop) • S41 - Safety edge with safety test (if contact 1-8 opens, after the stop there is a disengagement of a duration depending on the selection  → )	 NO  PH  P41  SE  S41
		S0 - Terminal 1-8 operation mode when open • ON - Enabled • OF - Disabled If enabled () with the automation idle (gate closed or partially open) all operations are prevented. If disabled () with the automation idle (gate closed or partially open) opening operations are permitted.	 ON  OF




































16.5 Complete menu - parameters description

<div> <div>IP2437EN</div> <div> <div>OM</div> <div>00</div> </div> </div>	<div> <div>OM - Operation Mode</div> <div>The menu allows to manage all the parameters used for operation modes of the automation (type of automation installed, predefined settings, automatic closure, etc.)</div> </div> <table> <tr> <th>Parameter</th><th>Description</th><th>Selections available</th></tr> <tr> <td data-bbox="215 229 295 413"> <div>AS</div> </td><td data-bbox="295 229 893 413"> <div>AS - Selection of the automation</div> <div>Allows to select the automation type (factory preset)</div> <ul style="list-style-type: none"> • NO - None • 4B - ION4B • 6B - ION6B <div>NOTE: the card performs a restart after a new value is selection.</div> </td><td data-bbox="893 229 1031 413"> <div>NO</div> <div>4B</div> </td></tr> <tr> <td data-bbox="215 413 295 501"> <div></div> </td><td data-bbox="295 413 893 501"> <div>WARNING: in case of replacement card, the display flashes alarm. No operation is allowed. The AS parameter must be first configured. This operation must be performed by qualified personnel.</div> </td><td data-bbox="893 413 1031 501"> <div>6B</div> </td></tr> <tr> <td data-bbox="215 501 295 579"> <div>DM</div> </td><td data-bbox="295 501 893 579"> <div>DM - Opening direction</div> <ul style="list-style-type: none"> • RT - right • LF - left </td><td data-bbox="893 501 1031 579"> <div>RT</div> <div>LF</div> </td></tr> <tr> <td data-bbox="215 579 295 707"> <div>AC</div> </td><td data-bbox="295 579 893 707"> <div>AC - Automatic closure enabling</div> <ul style="list-style-type: none"> • OF - Disabled • ON - Enabled • 1-2 - Dependent on status of terminal 20 (parameter 20 must set to 1-2) <div>NOTE: the card performs a restart after a new value is selection.</div> </td><td data-bbox="893 579 1031 707"> <div>OF</div> <div>ON</div> <div>1-2</div> </td></tr> <tr> <td data-bbox="215 707 295 916"> <div>TC</div> </td><td data-bbox="295 707 893 916"> <div>TC - Setting of automatic closing time [s]</div> <div>It is set with different intervals of sensitivity:</div> <ul style="list-style-type: none"> • from 0" to 59" with intervals of 1 second • from 1'0 to 1'5 with intervals of 10 seconds <div>For each interval, the display visualizes:</div> <ul style="list-style-type: none"> - 01 → 1 minute and 10 seconds - ... - 05 → 1 minute and 50 seconds • from 2' to 4' with intervals of 1 minute </td><td data-bbox="893 707 1031 916"> <div>00 ... 59</div> <div>10 ... 15</div> <div>20 ... 40</div> <div>05</div> </td></tr> <tr> <td data-bbox="215 916 295 1003"> <div>RP</div> </td><td data-bbox="295 916 893 1003"> <div>RP - Adjustment of partial opening measurement [%]</div> <div>This parameter adjusts the percentage of partial opening in relation to the total opening of the automation.</div> <ul style="list-style-type: none"> • from 10 to 99 % with intervals of 1 % </td><td data-bbox="893 916 1031 1003"> <div>10 ... 99</div> <div>30</div> </td></tr> <tr> <td data-bbox="215 1003 295 1211"> <div>TP</div> </td><td data-bbox="295 1003 893 1211"> <div>TP - Setting of automatic closing time after partial opening [s]</div> <div>It is set with different intervals of sensitivity.</div> <ul style="list-style-type: none"> • from 0" to 59" with intervals of 1 second • from 1'0 to 1'5 with intervals of 10 seconds <div>For each interval, the display visualizes:</div> <ul style="list-style-type: none"> - 01 → 1 minute and 10 seconds - ... - 05 → 1 minute and 50 seconds • from 2' to 4' with intervals of 1 minute </td><td data-bbox="893 1003 1031 1211"> <div>00 ... 59</div> <div>10 ... 15</div> <div>20 ... 40</div> <div>30</div> </td></tr> <tr> <td data-bbox="215 1211 295 1286"> <div>PP</div> </td><td data-bbox="295 1211 893 1286"> <div>PP - Setting of step-by-step sequence</div> <ul style="list-style-type: none"> • 00 - Opening-Stop-Closing-Opening • 01 - Opening-Stop-Closing-Stop-Opening </td><td data-bbox="893 1211 1031 1286"> <div>00</div> <div>01</div> </td></tr> <tr> <td data-bbox="215 1286 295 1361"> <div>S9</div> </td><td data-bbox="295 1286 893 1361"> <div>S9 - Stop mode in step-by-step sequence from command 1-5.</div> <ul style="list-style-type: none"> ON - Permanent OF - Temporary. </td><td data-bbox="893 1286 1031 1361"> <div>ON</div> <div>OF</div> </td></tr> <tr> <td data-bbox="215 1361 295 1469"> <div>SS</div> </td><td data-bbox="295 1361 893 1469"> <div>SS - Selection of automation status at start</div> <ul style="list-style-type: none"> OP - Open. CL - Closed. <div>Indicates how the control panel considers the automation at the time of switch-on, or after a POWER RESET command.</div> </td><td data-bbox="893 1361 1031 1469"> <div>OP</div> <div>CL</div> </td></tr> </table>	Parameter	Description	Selections available	<div>AS</div>	<div>AS - Selection of the automation</div> <div>Allows to select the automation type (factory preset)</div> <ul style="list-style-type: none"> • NO - None • 4B - ION4B • 6B - ION6B <div>NOTE: the card performs a restart after a new value is selection.</div>	<div>NO</div> <div>4B</div>	<div></div>	<div>WARNING: in case of replacement card, the display flashes alarm. No operation is allowed. The AS parameter must be first configured. This operation must be performed by qualified personnel.</div>	<div>6B</div>	<div>DM</div>	<div>DM - Opening direction</div> <ul style="list-style-type: none"> • RT - right • LF - left 	<div>RT</div> <div>LF</div>	<div>AC</div>	<div>AC - Automatic closure enabling</div> <ul style="list-style-type: none"> • OF - Disabled • ON - Enabled • 1-2 - Dependent on status of terminal 20 (parameter 20 must set to 1-2) <div>NOTE: the card performs a restart after a new value is selection.</div>	<div>OF</div> <div>ON</div> <div>1-2</div>	<div>TC</div>	<div>TC - Setting of automatic closing time [s]</div> <div>It is set with different intervals of sensitivity:</div> <ul style="list-style-type: none"> • from 0" to 59" with intervals of 1 second • from 1'0 to 1'5 with intervals of 10 seconds <div>For each interval, the display visualizes:</div> <ul style="list-style-type: none"> - 01 → 1 minute and 10 seconds - ... - 05 → 1 minute and 50 seconds • from 2' to 4' with intervals of 1 minute 	<div>00 ... 59</div> <div>10 ... 15</div> <div>20 ... 40</div> <div>05</div>	<div>RP</div>	<div>RP - Adjustment of partial opening measurement [%]</div> <div>This parameter adjusts the percentage of partial opening in relation to the total opening of the automation.</div> <ul style="list-style-type: none"> • from 10 to 99 % with intervals of 1 % 	<div>10 ... 99</div> <div>30</div>	<div>TP</div>	<div>TP - Setting of automatic closing time after partial opening [s]</div> <div>It is set with different intervals of sensitivity.</div> <ul style="list-style-type: none"> • from 0" to 59" with intervals of 1 second • from 1'0 to 1'5 with intervals of 10 seconds <div>For each interval, the display visualizes:</div> <ul style="list-style-type: none"> - 01 → 1 minute and 10 seconds - ... - 05 → 1 minute and 50 seconds • from 2' to 4' with intervals of 1 minute 	<div>00 ... 59</div> <div>10 ... 15</div> <div>20 ... 40</div> <div>30</div>	<div>PP</div>	<div>PP - Setting of step-by-step sequence</div> <ul style="list-style-type: none"> • 00 - Opening-Stop-Closing-Opening • 01 - Opening-Stop-Closing-Stop-Opening 	<div>00</div> <div>01</div>	<div>S9</div>	<div>S9 - Stop mode in step-by-step sequence from command 1-5.</div> <ul style="list-style-type: none"> ON - Permanent OF - Temporary. 	<div>ON</div> <div>OF</div>	<div>SS</div>	<div>SS - Selection of automation status at start</div> <ul style="list-style-type: none"> OP - Open. CL - Closed. <div>Indicates how the control panel considers the automation at the time of switch-on, or after a POWER RESET command.</div>	<div>OP</div> <div>CL</div>
Parameter	Description	Selections available																																
<div>AS</div>	<div>AS - Selection of the automation</div> <div>Allows to select the automation type (factory preset)</div> <ul style="list-style-type: none"> • NO - None • 4B - ION4B • 6B - ION6B <div>NOTE: the card performs a restart after a new value is selection.</div>	<div>NO</div> <div>4B</div>																																
<div></div>	<div>WARNING: in case of replacement card, the display flashes alarm. No operation is allowed. The AS parameter must be first configured. This operation must be performed by qualified personnel.</div>	<div>6B</div>																																
<div>DM</div>	<div>DM - Opening direction</div> <ul style="list-style-type: none"> • RT - right • LF - left 	<div>RT</div> <div>LF</div>																																
<div>AC</div>	<div>AC - Automatic closure enabling</div> <ul style="list-style-type: none"> • OF - Disabled • ON - Enabled • 1-2 - Dependent on status of terminal 20 (parameter 20 must set to 1-2) <div>NOTE: the card performs a restart after a new value is selection.</div>	<div>OF</div> <div>ON</div> <div>1-2</div>																																
<div>TC</div>	<div>TC - Setting of automatic closing time [s]</div> <div>It is set with different intervals of sensitivity:</div> <ul style="list-style-type: none"> • from 0" to 59" with intervals of 1 second • from 1'0 to 1'5 with intervals of 10 seconds <div>For each interval, the display visualizes:</div> <ul style="list-style-type: none"> - 01 → 1 minute and 10 seconds - ... - 05 → 1 minute and 50 seconds • from 2' to 4' with intervals of 1 minute 	<div>00 ... 59</div> <div>10 ... 15</div> <div>20 ... 40</div> <div>05</div>																																
<div>RP</div>	<div>RP - Adjustment of partial opening measurement [%]</div> <div>This parameter adjusts the percentage of partial opening in relation to the total opening of the automation.</div> <ul style="list-style-type: none"> • from 10 to 99 % with intervals of 1 % 	<div>10 ... 99</div> <div>30</div>																																
<div>TP</div>	<div>TP - Setting of automatic closing time after partial opening [s]</div> <div>It is set with different intervals of sensitivity.</div> <ul style="list-style-type: none"> • from 0" to 59" with intervals of 1 second • from 1'0 to 1'5 with intervals of 10 seconds <div>For each interval, the display visualizes:</div> <ul style="list-style-type: none"> - 01 → 1 minute and 10 seconds - ... - 05 → 1 minute and 50 seconds • from 2' to 4' with intervals of 1 minute 	<div>00 ... 59</div> <div>10 ... 15</div> <div>20 ... 40</div> <div>30</div>																																
<div>PP</div>	<div>PP - Setting of step-by-step sequence</div> <ul style="list-style-type: none"> • 00 - Opening-Stop-Closing-Opening • 01 - Opening-Stop-Closing-Stop-Opening 	<div>00</div> <div>01</div>																																
<div>S9</div>	<div>S9 - Stop mode in step-by-step sequence from command 1-5.</div> <ul style="list-style-type: none"> ON - Permanent OF - Temporary. 	<div>ON</div> <div>OF</div>																																
<div>SS</div>	<div>SS - Selection of automation status at start</div> <ul style="list-style-type: none"> OP - Open. CL - Closed. <div>Indicates how the control panel considers the automation at the time of switch-on, or after a POWER RESET command.</div>	<div>OP</div> <div>CL</div>																																



	<p>TS - Setting of renewal of automatic closing time after photocells safety device release [%]</p> <ul style="list-style-type: none"> • from 0 to 99% with intervals of 1%. <p>The count begins with the door fully open, (and the closing operation is performed even with automatic closure (RC) disabled).</p> <p>⚠ WARNING: automatic closure is not disabled on the third consecutive direction reversal.</p> <p>E.g.:</p> <ul style="list-style-type: none"> • TC = 1' • TS = 50% • Renewal of automatic closing time= 30" 	
	<p>W0 - Setting of pre-flashing time on opening [s]</p> <p>Adjustment of the lead time for the switch-on of the flashing light and courtesy light, in relation to the start of the opening operation from a voluntary command.</p> <ul style="list-style-type: none"> • from 0" to 5" with intervals of 1 second 	
	<p>WC - Setting of pre-flashing time on closing [s]</p> <p>Adjustment of the lead time for the switch-on of the flashing light and courtesy light in relation to the start of the closing operation from a voluntary command.</p> <ul style="list-style-type: none"> • from 0" to 5" with intervals of 1 second 	
	<p>NI - Enabling of NIO electronic anti-freeze system</p> <ul style="list-style-type: none"> • ON - Enabled • OF - Disabled <p>When enabled (ON), it maintains the efficiency of the motor even at low ambient temperatures.</p> <p>i NOTE: for correct operation, the control panel must be exposed to the same ambient temperature as the motors</p> <p>The intervention temperature for NIO can be set by selecting OM→TN.</p>	
	<p>TN - Setting of intervention temperature for the NIO electronic antifreeze system and automatic HS ramps [°C]</p> <p>This value does not refer to the ambient temperature, but to the internal control panel temperature.</p>	 
	<p>HS - Enabling ramps anti-freeze system</p> <ul style="list-style-type: none"> • ON - Enabled • OF - Disabled <p>When enabled (ON), at low ambient temperatures the start time ST increases up to the maximum value, the acceleration time TA and TB diminishes to the minimum value and diminishes the manoeuvre speed.</p> <p>i NOTE: for correct operation, the control panel must be exposed to the same ambient temperature as the motors.</p> <p>The intervention temperature HS can be set by selecting OM→TN.</p>	
	<p>TH - High temperature protection enable</p> <ul style="list-style-type: none"> • ON - Enabled • OF - Disabled <p>When enabled (ON), on reaching the maximum permissible control panel temperature (80°), the maximum automatic closing time is set to allow the system to cool down to acceptable temperatures.</p>	
	<p>HF - Heavy Traffic function</p> <ul style="list-style-type: none"> ON - Enabled OF - Disabled <p>When this function is enabled, the automatic reclosing time is increased automatically to 3 min in the event of a series of consecutive operations due to frequent aperture requests (e.g. at peak traffic times in a condominium application), to reduce wait times for users and to limit motor wear and the risk of overheating.</p>	

















	DS - Setting of display visualisation mode			
	• 00 - No visualisation			
	• 01 - Commands, safety devices and radio test. Display of countdown to automatic closure.			
	• 02 - Automation status			
	• 03 - Commands and safety devices			
	NOTE: the setting  allows you to see when a radio transmission is received, for range checks (RX and NX - see 16.2 par.)			
	PS - Predefined settings			
	It is used to load default settings for some parameters:			
	• DF- Default configuration			
	• AC - Automatic closure enabling			
	• TC - Setting of automatic closing time			
	• T5 - Terminal 5 operation mode			
	• RM - Radio receiver operation			
	• AM - Operation of AUX plug-in control board			
	• SS - Selection of automation status at start			
	• H0 - Predefined setting, residential use 0			
	• AC - Automatic closure enabling			
	• T5 - Terminal 5 operation mode			
	• RM - Radio receiver operation			
	• AM - Operation of AUX plug-in control board			
	• SS - Selection of automation status at start			
	• H1 - Predefined setting, residential use 1			
	• AC - Automatic closure enabling			
	• TC - Setting of automatic closing time			
	• T5 - Terminal 5 operation mode			
	• RM - Radio receiver operation			
	• AM - Operation of AUX plug-in control board			
	• SS - Selection of automation status at start			
	• C0 - Predefined setting, condominium use 0			
	• AC - Automatic closure enabling			
	• TC - Setting of automatic closing time			
	• T5 - Terminal 5 operation mode			
	• RM - Radio receiver operation			
	• AM - Operation of AUX plug-in control board			
	• SS - Selection of automation status at start			















































AA



















RA - Run Adjustment






























The menu allows to adjust all the run parameters (opening/closure speed, slowdown positions, obstacle thrust sensibility etc.)

Parameter	Description	Selections available
	VA - Opening speed [cm/s] • from 10 to 30 cm/s with intervals of 1 cm/s	 10 ... 30 20
	VC - Closing speed [cm/s] • from 10 to 30 cm/s with intervals of 1 cm/s	 10 ... 30 20
	R1 - Adjustment of thrust on obstacles and motor current during opening [%] The control panel is provided with a safety device which, in the case of an obstacle: - the movement is stopped, if outside the obstacle detection limit space, performs a disengagement operation. <div style="background-color: #e0f0ff; padding: 5px; margin: 10px 0;"> NOTE: the obstacle detection limit space when opening is defined by the type of limit switch installed, in the absence of a limit switch it is determined by the selection RA → 00. </div> • 00 – Minimum thrust (minimum current delta for obstacle detection) • 99 – Maximum thrust (maximum current delta for obstacle detection) The threshold is calculated dynamically as a delta on the motor current measured during the opening stroke.	 00 ... 99 30
	R2 - Adjustment of thrust on obstacles and motor current during closing [%] The control panel is provided with a safety device which, in the case of an obstacle: - closing, outside of the detection limit space, the system invert the movement; - closing, in the detection limit space, the system stoped the movement. <div style="background-color: #e0f0ff; padding: 5px; margin: 10px 0;"> NOTE: the obstacle detection limit space when closing is defined by the type of limit switch installed, in the absence of a limit switch it is determined by the selection RA → 00. </div> • 00 – Minimum thrust (minimum current delta for obstacle detection) • 99 – Maximum thrust (maximum current delta for obstacle detection) The threshold is calculated dynamically as a delta on the motor current measured during the closing stroke.	 00 ... 99 30
	OB - Adjustment of deceleration distance during opening [cm] Indicates the deceleration distance before reaching the maximum open position. • from 5 to 99 cm with intervals of 1 cm	 05 ... 99 60
	CB - Adjustment of deceleration distance during closing [cm] Indicates the deceleration distance before reaching the closing position. • from 5 to 99 cm with intervals of 1 cm	 05 ... 99 60
	PO - Adjustment of approach speed during opening [cm/s] Indicates the speed from the end of the deceleration ramp to the end of the opening stroke • from 3 to 10 cm/s with intervals of 1 cm/s <div style="background-color: #e0f0ff; padding: 5px; margin: 10px 0;"> NOTE: gradually increase the approach speed if there is a series of quick vibrations (chattering) in heavy gates installed with a slight incline. </div>	 03 ... 10 05

  		PC - Adjustment of approach speed during closing [cm/s] • from 3 to 10 cm/s with intervals of 1 cm/s	 03 ... 10 05
		OO - Obstacle detection limit during opening [cm] Indicates the distance from the opening stop at which disengagement is deactivated. • from 5 to 99 cm with intervals of 1 cm  NOTE: not active if  →  →  or if  →  → 	 05 ... 99 40
		OC - Obstacle detection limit during closure [cm] Indicates the distance from the closure stop at which reversal is deactivated. • from 5 to 99 cm with intervals of 1 cm  NOTE: not active if  →  →  or if  →  → 	 05 ... 99 40
		VR - Setting of learning speed [cm/s] • from 5 to 10 cm/s with intervals of 1 cm/s	 05 ... 10 08
		VM - Initial movement speed [cm/s] • from 0 to 15 cm/s with intervals of 1 cm/s	 00 ... 15 05
		TA - Adjustment of acceleration time during opening [s] Regulates the slope of the acceleration ramp during opening • from 0.5 to 9.9 s with intervals of 0.1 s	 0.5 ... 9.9 2.0
		TQ - Adjustment of acceleration time during closure [s] Regulates the slope of the acceleration ramp during closing • from 0.5 to 9.9 s with intervals of 0.1 s	 0.5 ... 9.9 2.0
		TD - Adjustment of deceleration time during opening [%] Regulates the slope of the deceleration ramp during opening. • from 10 to 99 % with intervals of 1 %	 10 ... 99 75
		TU - Adjustment of deceleration time during closure [%] Regulates the slope of the deceleration ramp during closing. • from 10 to 99 % with intervals of 1 %	 10 ... 99 75
		DO - Setting of disengagement on stop during opening [mm] Regulates the distance of the disengagement on the mechanical opening stop. • 00 - Disabled • from 1 to 15 mm with intervals of 1 mm	 00 ... 15 07
		DC - Setting of disengagement on stop during closure [mm] Regulates the distance of the disengagement on the mechanical closing stop. • 00 - Disabled • from 1 to 15 mm with intervals of 1 mm	 00 ... 15 07
		DE - Disengagement setting if an edge is triggered [cm] Regulates the disengagement distance when an edge (active or passive) is triggered during opening or closure. • 00 - Deactivated • from 1 to 20 cm with intervals of 1 cm	 00 ... 20 10
		ST - Adjustment of start time [s] • from 0.5 to 3.0 s with intervals of 0.1 s	 0.5 ... 3.0 2.0

		DT - Adjustment of obstacle recognition time [s/100] • from 10 to 60 s/100 with intervals of 1 s/100  NOTE: the parameter is adjusted in hundredths of a second	
		MP - Start-up at maximum power • ON - During start-up it increases the thrust on obstacles to maximum • OF - During start-up, the thrust on obstacles is the one adjusted by P1 - P2 .	
		OT - Selection of type of obstacle identification • 00 - Overcurrent or gate stopped • 01 - Overcurrent • 02 - Door stopped	

		IO - Input/Output Configuration The menu allows to configure the inputs/outputs functionalities of the automation.	
	Parameter	Description	Selections available
		FA - Selection of opening limit switch mode • NO - None • SX - Stop limit switch (after activation, the gate stops its movement) • PX - Proximity limit switch (after activation, the gate continues as far as the end stop and any obstacle is considered a stop)	
		FC - Selection of closing limit switch mode • NO - None • SX - Stop limit switch (after activation, the gate stops its movement) • PX - Proximity limit switch (after activation, the gate continues as far as the end stop and any obstacle is considered a stop)	
		R9 - Terminal 9 operation mode • NO - disabled. • 9P - open state of the input triggers a permanent stop (default). • 9T - open state of the input triggers a temporary stop. Once contact closes, an automatic closure time is activated (if enabled). • HR - With the input open, the automation operates in "operator present" mode	
		T5 - Terminal 5 operation mode This parameter is associated to the functionality of the terminal 30-5 • 1-5 - Step-by-step • 1-3 - Opening	
		64 - Functioning of safety stop/closing command • 1-4 - Closing. Contact NO • 1-6 - Safety. Contact NC	
		AM - Operation of AUX plug-in control board • 1-5 - Step-by-step • 1-3 - Opening	
		20 - Partial opening command of terminal 30-20 • P3 - Partial opening command • 1-2 - Enabling of automatic closure	
		PT - Fixed partial opening • ON - Enabled • OF - Disabled If ON , a partial opening command given on the partial opening position is ignored. With contact 30-20 closed (for example with the timer or manual selector), the gate will partially open. If it is then fully opened (opening command) and reclosed (even with automatic closure), it will stop at the partial opening position.	

			D6 - Selection of device connected to terminals 1-6 <ul style="list-style-type: none"> • N0 - None • PH - Photocells • P41 - Photocells with safety test • SE - Safety edge (if contact 1-6 opens, there is a disengagement of 10 cm after the stop) • S41 - Safety edge with safety test (if contact 1-6 opens, after the stop there is a disengagement of a duration depending on the selection RR → DE) 	    
			SM - Operation mode of terminals 1-6 <ul style="list-style-type: none"> • 00 - During the operation, the opening of the safety contact stops the movement (with disengagement if DE → SE/S41). • 01 - During the operation, the opening of the safety contact stops the movement (with disengagement if DE → SE/S41). When the contact closes again, the operation is resumed. • 02 - During the operation, opening of the safety contact stops the movement (with disengagement if DE → SE/S41). When the contact closes again, an opening operation is performed. • 03 - During the closing operation, the opening of the safety contact reverses the movement. During the opening operation, the safety device is ignored. • 04 - During the opening operation, the opening of the safety contact stops the movement (with disengagement if DE → SE/S41). When the contact closes again, the opening operation is resumed. During the closing operation, the safety device is ignored. • 05 - During the closing operation, the opening of the safety contact stops and reverses the movement. During the opening operation, the opening of the safety contact stops the movement (with disengagement if DE → SE/S41). • 06 - During a maneuver, the opening of the safety contact stops the movement. When the contact closes again, automatic closing is disabled. 	      
			D8 - Selection of device connected to terminals 1-8 <ul style="list-style-type: none"> • N0 - None • PH - Photocells • P41 - Photocells with safety test • SE - Safety edge (if contact 1-8 opens, there is a disengagement of 10 cm after the stop) • S41 - Safety edge with safety test (if contact 1-8 opens, after the stop there is a disengagement of a duration depending on the selection RR → DE) 	    
			S0 - Terminal 1-8 operation mode when open <ul style="list-style-type: none"> • ON - Enabled • OF - Disabled <p>If enabled (ON) with the automation idle (gate closed or partially open) all operations are prevented.</p> <p>If disabled (OF) with the automation idle (gate closed or partially open) opening operations are permitted.</p>	 
			68 - Selection of the device simultaneously connected to terminals 1-6 and 1-8 <ul style="list-style-type: none"> • N0 - None • SE - Safety edge • S41 - Safety edge with safety test <p>If different from N0, the simultaneous opening of inputs 1-6 and 1-8 causes:</p> <ul style="list-style-type: none"> • movement stop and reversal during a closing operation. • movement stop and disengagement of a duration depending on the selection RR → DE during an opening operation. 	  

	<p>LP - Function of output +LP-</p> <ul style="list-style-type: none"> • 00 - courtesy light • 01 - electric lock (activated for a time defined by parameter LP) • 02 - electric lock + release stroke (time defined by parameter LP) • 03 - ON-OFF flashing light (active with motor in action) • 04 - ON-OFF flashing light for LED without oscillator (with motor in action) • 05 - ON for LED flashing light with internal oscillator • 06 - proportional indicator light for open gate (with signal of battery operation) • 07 - fixed indicator light for open gate (automation not closed) • 08 - automation closed (activated with gate fully closed) • 09 - automation open (activated with gate fully open) • 10 - automation moving (can also be used for electromagnets that need to be powered throughout the operation) • 11 - automation opening • 12 - automation closing • 13 - maintenance alarm • 14 - Low batteries signal • ON - output always active 	
	<p>13 - Function of output 13</p> <ul style="list-style-type: none"> • 00 - courtesy light • 01 - electric lock (activated for a time defined by parameter LP) • 02 - electric lock + release stroke (time defined by parameter LP) • 03 - ON-OFF flashing light (active with motor in action) • 04 - ON-OFF flashing light for LED without oscillator (with motor in action) • 05 - ON for LED flashing light with internal oscillator • 06 - proportional indicator light for open gate (with signal of battery operation) • 07 - fixed indicator light for open gate (automation not closed) • 08 - automation closed (activated with gate fully closed) • 09 - automation open (activated with gate fully open) • 10 - automation moving (can also be used for electromagnets that need to be powered throughout the operation) • 11 - automation opening • 12 - automation closing • 13 - maintenance alarm • 14 - Low batteries signal • ON - output always active 	
	<p>LU - Setting the courtesy light switch-on extra time [s] To enable the parameter, set IO→LP→00 (courtesy light). It is set with different intervals of sensitivity.</p> <ul style="list-style-type: none"> • NO - Disabled • from 01" to 59" with intervals of 1 second • from 1'0 to 2' with intervals of 10 seconds <p>For each interval, the display visualizes:</p> <ul style="list-style-type: none"> - 01 → 1 minute and 10 seconds - ... - 05 → 1 minute and 50 seconds • from 2' to 4' with intervals of 1 minute • ON - Permanently enabled (switched off via remote control) <p>i NOTE: the courtesy light switches on at the start of each operation</p>	









		<p>LG - Switch-on time for independently commanded courtesy light [sec, min, hh]</p> <p>To enable the parameter, set IO→LP→00 selection as the courtesy light.</p> <ul style="list-style-type: none"> • NO - disabled • from 01 to 59 - from 1 second to 59 seconds with intervals of 1 second • from 1'0 to 1'5 - from 1 minute to 1 minute and 50 seconds with intervals of 10 seconds • 2' - 2 minutes • from 03. to 59. - from 3 minutes to 59 minutes with intervals of 1 minute • from 0.1. to 1.2. - from 1 hour to 12 hours with intervals of 1 hour • ON - Switched on and off with remote control or Wall-Station <p>NOTE: the switching on of the light does not depend on the start of an operation but can be commanded separately using the remote-control.</p>	      
		<p>LR - Electric lock release time [s]</p> <p>If enabled, this indicates the electric lock activation time at the start of every opening operation with the automation closed.</p>	 
		<p>PV - Solar panel power supply (future use)</p> <ul style="list-style-type: none"> • ON - Enabled • OF - Disabled 	
		<p>ES - Energy-saving (disconnecting accessories connected to terminals 0-1)</p> <ul style="list-style-type: none"> • ON - Enabled (the red point on the right of the display flashes every 5 s). • OF - Disabled <p>Power supply disconnection mode is activated after 5' with the gate closed, or when the gate is idle and automatic closure is not enabled.</p> <p>NOTE: the automation resumes its normal operation when a command is received on the radio board or following a terminals 30-5.</p> <p>WARNING: The installer, in the case of installing an accessory that requires power always on, can set the selection to OFF and disable the function.</p>	
		<p>LB - Indication that batteries are almost flat</p> <ul style="list-style-type: none"> • 00 - Visualisation on display (alarm message 30) • 01 - Visualisation on flashing light (with the automation idle, 2 flashes are made and then repeated every hour) and on display (alarm message 30) • 02 - Visualisation on "open gate" indicator light (with the automation closed, 2 flashes are made and then repeated every hour) and on display (alarm message 30) 	 
		<p>LL - Voltage threshold for indicating that batteries are almost flat (V)</p> <ul style="list-style-type: none"> • 22 - Minimum • 28 - Maximum <p>NOTE: it is set with an interval of sensitivity of 0.5 V shown when the decimal point on the right lights up.</p>	 
		<p>BO - Battery mode</p> <ul style="list-style-type: none"> • 00 - Anti-panic (performs the opening operation following a mains supply failure. The automation opens but does not accept any other commands until the mains supply has been restored). • 01 - Continuous operation - the last operation performed before control panel switch-off with flat batteries will be an opening. • 02 - Continuous operation - the last operation performed before control panel switch-off will with flat batteries be an closure. 	 



R0

R0 - Radio Operations and Connectivity

The menu is used to manage all parameters for the radio/wireless functions of the control panel

Parameter	Description	Selections available
EP	EP - encrypted radios for remote controls (AES 128 and PROTECTED modes) If the possibility to receive coded messages is enabled, the control panel will be compatible with remote controls of the "ENCRYPTED" type.	ON OFF
SR	SR - Remote control storage  By pressing  SR starts flashing and it is possible to associate the desired buttons. After OK is displayed, SR flashes again on the display and it is possible to associate the next button. To exit, press  for 2 seconds and move on to the next item. NOTE: if the display shows NO flashing, the remote control may already be memorized.	
RM	RM - Radio receiver operation This is the function associated to radio command when only one channel is stored (independently which one is) • 1-5 - Step-by-step • 1-3 - Opening	15 13
TX	TX - Visualization of counter showing remote control stored 	
MU	MU - Setting of the maximum number of remote controls that can be stored in the memory You can store a maximum of 100 or 200 remote control codes.  • 10 - 100 remote controls that can be stored • 20 - 200 remote controls that can be stored WARNING: selecting MU → 20 (200 remote controls), the configurations U1 and U2 saved with the PF → SH command will be lost. This also applies for the last configuration reloaded with RL . In addition, new configurations cannot be saved on U1 and U2 .	10 20
ER	ER - Deletion of a single remote control 	
EA	EA - Total memory deletion  It requires double confirm. Press  for 2 seconds, release and press again for other 2 seconds.	






















		<p>C1, C2, C3, C4 - Selection of CH1, CH2, CH3, CH4 function of stored remote control</p> <ul style="list-style-type: none"> • NO - No setting selected • 1-3 - Opening command • 1-4 - Closing command • 1-5 - Step-by-step command • P3 - Partial opening command • LG - Command to switch the courtesy light on/off • 1-9 - STOP command <p>If even just one (any) CH key of the remote control is stored, the opening or stepby- step command is implemented.</p> <p>i NOTE: the 1-3 (opening) and 1-5 (step-by-step) options are available as alternatives, and depend on the selection of PM.</p> <p>If 2-4 CH keys of a single remote control are stored, the functions matched in the factory with the CH keys are as follows:</p> <ul style="list-style-type: none"> • CH1 = opening/step-by-step command • CH2 = partial opening command • CH3 = courtesy light on/off command • CH4 = STOP command 	
		<p>RE - Setting memory opening from remote control</p> <ul style="list-style-type: none"> • OF - Disabled • ON - Enabled. When enabled (ON), the remote programming is activated. To store new remote controls without using the control panel, refer to the remote control instructions. <p>i NOTE: make sure you do not accidentally memorise unwanted remote controls.</p>	
		<p>MS - Backward compatibility setting with older generation GOL4 remote controls</p> <ul style="list-style-type: none"> • OF - Compatibility with old generation GOL4 and new ZEN remote controls • ON - Compatibility with ZEN series remote controls <p>i NOTE: MS= ON is recommended if only ZEN series remote controls are used on the system.</p>	
		<p>RK - Menu navigation using remote control keyboard</p> <ul style="list-style-type: none"> • ON - Enabled • OF - Disabled <p>With the display turned off, quickly type in the sequence of keys 3 3 2 4 1 from the stored remote control you want to use. Make sure all the CH keys are stored.</p> <p>⚠ WARNING: during navigation with a remote control keyboard ALL the stored remote controls are inactive.</p> <p>To make viewing and adjustment easier (avoiding the need to continuously press the remote control), press the or key once to begin slowly scrolling through the parameters. This scrolling movement is faster if the or key is pressed twice. To stop the scrolling, press . To confirm your choice of parameter, press again. To test any new setting, switch off the display and issue an opening command using key 3. Navigation using a remote control keyboard is automatically disabled after 4 minutes of inactivity or by setting RK → OF.</p>	
		<p>FQ - Radio frequency selection</p> <p>The visible parameters depend by the Remote Connectivity Board (RCB) plugged in (J9 connector).</p> <ul style="list-style-type: none"> • NO - None RCB plugged in • 43 - Radio 433MHz (RCB50E or RCB100E plugged in) • 86 - Radio 868MHz (RCB50E or RCB100E plugged in) 	

	<p>VL - Vacation mode lock/unlock Radio commands transmitted by radio frequency devices (radio controls and digital radio keypad) are disabled.</p> <ul style="list-style-type: none"> • ON - Vacation mode enable. Lock out all remote-control (radio frequency) devices • OF - Vacation mode disable. Unlock all remote-control (radio frequency) devices <p> NOTE: if enabled, the display shows VL each time a radio command is received</p>	
	<p>BT - Bluetooth® mode</p> <ul style="list-style-type: none"> • ON - Enabled • OF - Disabled 	
	<p>WF - Setting of WiFi functionality (future use) It is used to enable or disable the WiFi functionality .</p> <ul style="list-style-type: none"> • ON - WiFi is enabled • OF - WiFi is disabled <p> WARNING: the enabling of WiFi will increase the power consumption; in this case be aware that it is not guaranteed the fulfillment of limits for standby consumption.</p>	
	<p>WR - Request to restart the connected WiFi device (future use)</p> <p> → </p> <p> NOTE: the item is present only if a WiFi device is connected.</p>	
	<p>MA - Mobile App access management Allows viewing, granting and resetting access permissions for the Mobile App: DITEC GATE CONNECT PRO</p> <p>To view the type of access present on the operator, briefly press ENTER:</p> <p> → </p> <p>The type of access present on the operator will be displayed:</p> <p>00 - No access 01 - Temporary access (duration 1 hour) 02 - Access with PIN 03 - Access from cloud (for future implementation)</p> <p>If no permission is present (MA = 00), when temporary access is requested from the App the message 'MA', confirm the request by holding down the ENTER key until the OK appears.</p> <p> → → </p> <p>The value of MA will become 01. If necessary, press the ESC key to exit the menu.</p> <p>To set up PIN access, follow the instructions on the Mobile App: DITEC GATE CONNECT</p> <p>RESET PERMITS (end-user version) Press ENTER for 2 seconds; the display flashes. Release and press again for another 2 seconds. The value of MA will become 00.</p> <p> → → → → </p>	



Diagnostic Functions

The menu allows to manage all other parameters used for additional services (diagnostic counters, FW updating, energy saving, etc.).

Parameter	Description	Selections available
	SP - Setting the password   NOTE: this can only be selected when the password is not set. Setting the password prevents unauthorised personnel from accessing selections and adjustments. You can delete the set password by selecting the sequence: JR1=ON, JR1=OFF, JR1=ON	
	IP - Inserimento della password   NOTE: this can only be selected when the password is set. When the password is not inserted, you can access the display mode regardless of the selection made with JR1. When the password is inserted, you can access in maintenance mode.	
	CU - Visualization of the firmware version on the control panel 	
	UP - Firmware update Activates the card bootloader in order to update the firmware. Contact after-sales department for more information 	
	AL - Alarm counter Used to view, in sequence, the counters of alarms that have been triggered at least once [alarm code + number of times triggered]. With  and  , you can scroll through all the counters and see all the alarms recorded.	
	AH - Alarm log Used to view, in sequence, alarms that have been triggered (maximum 20). With  and  , you can scroll through the entire alarm log. The display shows the alarm number and code, alternated. The highest number corresponds to the most recent alarm and the lowest number [0] corresponds to the oldest alarm.	
	AR - Alarm reset Resets all the alarms in the memory (counters and log).   NOTE: when the installation has been completed, you are advised to delete the alarms in order to facilitate future checks.	
	CV - Display of total manoeuvres counter 	



CP - Display of partial manoeuvres counter

→ → → → → 716 manoeuvres (example)

ZP - Reset of partial manoeuvres counter

→ →
 ⌚ 2"

For correct functioning, you are advised to reset the partial manoeuvres counter:

- after maintenance work;
- after setting the maintenance alarm interval.

CA - Setting the maintenance alarm (factory setting - alarm deactivated: 0.0 00. 00)

You can set the required number of operations (regarding the partial manoeuvres counter) for signaling the maintenance alarm.

WARNING: when the set number of operations is reached, the alarm message appears on the display .

OA - Selecting maintenance alarm display mode

- 00 - Visualization on display (alarm message)
- 01 - Visualization on flashing light (with the automation idle, 4 flashes are made and then repeated every hour) on display (alarm message)

CH - Display of power supply hour counter

→ → → → → 215 hours (example)

BH - Visualization of counter for power supply hours via battery

→ → → → → 215 hours (example)

SV - Saving user configuration on control panel storage module

→ → → → → →
 (example) ⌚ 2"

WARNING: if the display visualizes flashing , the memory module may not be installed.

RC - Configuration loading

→ → → → → →
 (example) ⌚ 2"

It's possible to load the user configurations previously stored and on the memory module of the control panel.

RL - Loading of last configuration set

→ →
 ⌚ 2"

The control panel automatically saves the last configuration set, and keeps it memorized in the storage module. In the event of a fault or the replacement of the control panel, the last configuration of the automation can be restored by inserting the storage module and loading the last configuration set.



	EU - Erasing of user configurations and last configuration set in the storage module
	IM - Motor current visualization
	TB - Permanent display of the internal control panel temperature [°C] • ON - Enabled • OF - Disabled <div> </div>
	TT - Display min / max temperatures recorded • by pressing for 2 seconds the values are reset • minimum value with active right point
	TF - Limit switch test Only FA / FC are displayed when the respective limit switches are configured and active. If the limit switches are active but not configured: • FA = N.O. (both active points) • FC = NO (no active point) <div> </div>
	BL - Visualization of Battery voltage level The parameter shows the battery voltage level: • Lo - Automation stopped. Battery voltage level is low (≤ 22 V) • 22 - Battery voltage level ≥ 22 V and < 23 V • 23 - Battery voltage level ≥ 23 V and < 24 V • 24 - Battery voltage level ≥ 24 V and < 25 V • 25 - Battery voltage level ≥ 25 V and < 26 V • 26 - Battery voltage level ≥ 26 V and < 27 V • 27 - Battery voltage level ≥ 27 V and < 28 V • 28 - Battery voltage level ≥ 28 V <div> </div> <div> NOTE: the parameter is visible in the menu if the main power supply is missing and the battery kit is connected. In battery mode, when there is no power supply, the automation speed is reduced to a maximum of 15 cm/s. </div>
	EL - Efficiency level of the automation • At first start-up, the automation performs an acquisition operation and defines an efficiency level. This value can be used to assess the mechanical quality of the gate and to understand a suitable automation choice. In cases where the value is lower than 90%, mechanical maintenance is recommended to restore efficiency or the adoption of an automation with higher performance (e.g. motor with higher power). • During normal use, this parameter indicates the efficiency of the automation, updating its degradation status in real time: • 90%-99% High efficiency level, automation in excellent condition. • 50%-89% Medium efficiency level, performance starts to degrade. • 10%-49% Low efficiency level, performance is degraded, and maintenance is required. <div> NOTE: the reference level is the level set in the RF parameter. </div>
	RD - Resetting of factory settings

17. Signals visualised on the display



NOTE: depending on the type of automation and control panel, certain visualisations may not be available.

17.1 Display of automation status

- 01 → 05 → 02

01 → 02











Display	Description
	Automation closed
	Automation closed Release door open
	Automation open
	Automation open Release door open
	Automation stopped in intermediate position
	Automation stopped in intermediate position Release door open
	Automation closing
	Automation that slows down during closing
	Automation opening
	Automation that slows down during opening



NOTE: the automation status display mode is only visible with Display visualisation mode set to **02**.

• **01** → **05** → **02**

01 → **02**

Display	Description
	Automation closed
	Automation closed Release door open
	Automation open
	Automation open Release door open
	Automation stopped in intermediate position
	Automation stopped in intermediate position Release door open
	Automation closing
	Automation that slows down during closing
	Automation opening
	Automation that slows down during opening

17.2 Display of safety devices and commands

• 0M→35→01 / 0M→35→03

Display	Description	Display	Description
12	1-2 - Automatic closing activation command	68	68 - Selection of the device simultaneously connected to terminals 1-6 and 1-8
13	1-3 - Opening command	16	1-6 - Safety device with opening and closing stop
14	1-4 - Closing command	51	S1. - Detection of stop during closure
15	1-5 - Step-by-step command	18	1-8 - Safety with closing reversal
P3	P3 - Partial opening command.	19	1-9 - STOP command
4P	4P - Closing command with operator present	3P	3P - Opening command with operator present
RX	RX - Radio reception (of any memorised key of a transmitter present in the memory)	52	S2. - Detection of stop during opening
NX	NX - Radio reception (of any non-memorised key) NOTE: with the selection 0M→35→01, it is also visualised when a command is received from a non-stored transmitter.	00	00.- Obstacle detection area reached during opening
EX	EX - Rolling-code radio reception out of sequence	0C	0C. Obstacle detection area reached during closure
EP	EP - Radio reception not complying with the parameter configuration 00→EP	RV	RV - Enabling/disabling of built-in radio receiver via RX
CX	CX - Command received from AUX board	MQ	MQ - Learning operation of mechanical end stops in progress
JR1	JR1 - Variation of the JR1 jumper status	HT	HT - Heating of the motors (NIO function) in progress
VL	VL - radio controls disabled ('Vacation Mode' parameter active)	HS	HS - Sharp NIO start-up
SW	SW - Release door open When the release door is closed, the control panel performs a RESET (allarme ). It is possible to ignore the reset by holding down the  +  keys for 3 seconds until the  tops flashing.	FC	FC. - Closure limit switch
		FA	FA. - Opening limit switch

 NOTE: if you return to the menu, the reset is reactivated.

 WARNING: If the RESET is disabled, make sure not to move the gate manually.

17.3 Visualisation of alarms and faults

Type of alarm	Display	Description	Operation
Mechanical alarm		M0 - Automation not configured	Check the configuration of the parameter R5
		M3 - Automation blocked	Check the mechanical parts
		M4 - Motor short circuit	Check connection of motor
		M8 - Stroke too long	Check the rack / chain belt
		M9 - Stroke too short	Manually check that the gate moves freely
		MB - Absence of motor during an operation	Check connection of motor
		MD - Irregular operation of the opening limit switch If the limit switch is configured but can't be found, each stop (from the OB deceleration start point) is seen as an obstacle and indicated with MI .	Check connection of the opening limit switch
		ME - Irregular operation of the closure limit switch If the limit switch is configured but can't be found, each stop (from the CB deceleration start point) is seen as an obstacle and indicated with ME .	Check connection of the closure limit switch.
		MI - Detection of fifth consecutive obstacle	Check for the presence of permanent obstacles along the stroke of the automation
		ML - Inverted limit switches	Check the positioning and connection of the limit switches. Also check the motor connection
		OD - Obstacle during opening	Check for the presence of obstacles along the automation stroke
		OE - Obstacle during closure	Check for the presence of obstacles along the automation stroke
		OF - Automation blocked on opening	Check the mechanical parts and make sure there are no obstacles along the automation stroke
		OG - Automation blocked on closure	Check the mechanical parts and make sure there are no obstacles along the automation stroke
Power supply Settings		S6 - Incorrect setting of safety device test	Check the configuration of parameters SB , SB , SB . If SB → S4 , SB and SB cannot be P4 or S4 .

	I5 - No voltage 0-1 (faulty voltage regulator or short-circuit on accessories)	Check there is no short circuit in connection 0-1. If the problem persists, replace the control panel.
	I6 - Excessive voltage 0-1 (faulty voltage regulator)	Replace the control panel.
	I7 - Internal parameter error - value outside limits	Reset. If the problem persists, replace the control panel.
	I8 - Program sequence error	Reset. If the problem persists, replace the control panel.
	IA - Internal parameter error (EEPROM/FLASH)	Reset. If the problem persists, replace the control panel.
	IB - Internal parameter error (RAM)	Reset. If the problem persists, replace the control panel.
	IC - Operation time-out error (>5 min or >7 min in learning mode)	Manually check that the gate moves freely. If the problem persists, replace the control panel.
	IE - Power supply circuit fault	Reset. If the problem persists, replace the control panel.
	IM - MOSFET alarm - motor in short circuit or always ON	Reset. If the problem persists, replace the control panel. Check the settings / operating of any limit switches.
	IO - Interrupted motor power circuit (motor MOSFET open or always OFF)	Reset. If the problem persists, replace the control panel.
	IR - Motor relay error	Reset. If the problem persists, replace the control panel.
	IS - Error on motor current read circuit test	Reset. If the problem persists, replace the control panel.
	IU - Error on motor voltage read circuit test	Reset. If the problem persists, replace the control panel.
	TH - Intervention of high temperature safety device	Do not carry out any operations. If the problem persists, contact Technical Service.
	VH - Automation blocked due to high temperature	Do not carry out any operations. If the problem persists, contact Technical Service.
	XX - Firmware reset commanded by the simultaneous pressing of the  +  keys	
	WD - Firmware reset not commanded	

Radio operations alarm		R0 - Insertion of a storage module containing over 100 stored remote controls WARNING: the R0 → MU → 20 setting is made automatically	To save the system configurations on the storage module, delete any stored remote controls and bring the total to less than 100. Set R0 → MU → 10
		R3 - Storage module not detected	Insert a storage module
		R4 - Storage module not compatible with the control panel	Insert a compatible storage module
		R5 - No serial communication with the storage module	Replace the storage module
		R6 - Insertion of a specific storage module for testing	
		RV - Plug-in radio boards	
Power supply alarm		P0 - No mains voltage	Check the control panel is powered correctly. Check the line fuse. Check the mains power supply.
		P1 - Microswitch voltage too low	Check the control panel is powered correctly
Battery alarm		B0 - Battery almost flat	Check battery voltage. Replace battery.
Accessories alarm		A0 - Failure of test of safety sensor on contact 6	Check the device SOFA1-A2 is working correctly If the supplementary SOf board is not inserted, check the safety test is disabled
		A1 - Simultaneous safety sensor test on contacts 6 and 8 failed	Check the wiring and correct operation of the safety sensor
		A3 - Failure of test of safety sensor on contact 8	Check the device SOFA1-A2 is working correctly If the supplementary SOf board is not inserted, check the safety test is disabled
		A7 - Incorrect connection of contact 9 to terminal 41	Check that terminal 1 and 9 are correctly connected
		A9 - Overload on output +LP-	Check the device connected to output +LP- is working properly



WARNING: the visualisation of alarms and faults is possible with any visualisation selection. The signalling of alarm messages takes priority over all other displays.


18. Troubleshooting

Problem	Possible cause	Alarm signalling	Operation
The control panel does not switch on	No power supply.		Check the power supply cable and the relative wiring
The automation does not open or close	No power.		Check power supply cable.
	Short circuited accessories	I5	Disconnect all accessories from terminals 0-1 (a voltage of 24 V _{DC} must be present) and reconnect them one at a time. Contact Technical Service.
	Blown line fuse.		Replace fuse.
	Safety contacts are open.	I6 I8 68	Check that the safety contacts are closed correctly (NC).
	Safety contacts not correctly connected or self-controlled safety edge not functioning correctly.	A0 I6 A1 I8 A3 68	Check connections to terminals 6-8 on control panel and connections to the self-controlled safety edge.
	Photocells activated.	I6 I8	Check that the photocells are clean and operating correctly.
	The automatic closure does not work.		Issue any command. If the problem persists, contact Technical Service.
	Motor fault	M8 M4	Check motor connection, if the problem persists, contact Technical Service.
	Mechanical fault	M3 M8	Check the rack and transmission chain, and/or the mechanical parts.
	Release microswitch open	5W	Check that the hatch is closed correctly and the microswitch makes contact.
	Faulty control panel	I7 IE I8 IM IA IO IB IR	Contact Technical Service.
	Both limit switches are active.	FA FC	Check the connection of the limit switches

Problem	Possible cause	Alarm signalling	Operation
The external safety devices are not activated	Incorrect connections between the photocells and the control panel.		Check that P6/P8 is displayed. Connect NC safety contacts together in series and remove any jumpers on the control panel terminal board. Check the setting of I0→I6 and I0→I8 .
The automation opens/closes briefly and then stops	There is a presence of friction.	MI M9 IC	Manually check that the automation moves freely and check the R1/R2 adjustment. Contact Technical Service.
The remote control has limited range and does not work with the automation moving.	The radio transmission is impeded by metal structures and reinforced concrete walls.		Install the antenna outside. Replace the transmitter batteries.
The remote control does not work	No storage module or incorrect storage module.	R0 R3 R5	Switch the automation off and plug in the correct storage module. Check the correct memorisation of the transmitters on the built-in radio. If there is a fault with the radio receiver that is built into the control panel, the remote control codes can be read by removing the storage module.
The flashing light is not working	The wires of the flashing light are detached or have short circuited.	R9	Check the connections. If the problem persists, contact Technical Service.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by ASSA ABLOY Entrance Systems AB is under license.

All the rights concerning this material are the exclusive property of ASSA ABLOY Entrance Systems AB. Although the contents of this publication have been drawn up with the greatest care, ASSA ABLOY Entrance Systems AB cannot be held responsible in any way for any damage caused by mistakes or omissions in this publication. We reserve the right to make changes without prior notice. Copying, scanning or changing in any way is expressly forbidden unless authorised in writing by ASSA ABLOY Entrance Systems AB.

 The crossed-out wheeled bin symbol indicates that the product should be disposed of separately from normal household waste. The product should be recycled in accordance with local environmental regulations for waste disposal. By separating a product marked with this symbol from household waste, you will help reduce the volume of waste sent to incinerators or land-fill and minimise any potential negative impact on human health and the environment.



ASSA ABLOY Entrance Systems AB
Lodjursgatan 10
SE-261 44, Landskrona
Sweden
© ASSA ABLOY