



Ditec E1HBOX Quick Reference

 Before installing the product, carefully read the instructions.


1. ELECTRICAL CONNECTIONS FOR STANDARD INSTALLATION




2. Limit switch connections




3. Usage with limit switches




4. E1HBOX standard setting



5. Radio enabling



6. Automatic closing time setting



For different setting and further information consult the automation instruction manual, the control panel instruction manual and radio instruction manual.

DITEC S.p.A. Via Mons. Banfi, 3 21042 Caronno P.lla (VA) Italy Tel. +39 02 963911 Fax +39 02 9650314
www.ditecentrematic.com ditec@ditecva.com

Dítec
ENTRE//MATIC

